



Tensor[®]

**ENVIRONMENTAL
TIPS**

TOP TIPS

Unlock The Full Potential Of Your Tensor Adhesives

THE BLOOMING EFFECT



When adhesives tack off, the solvent and propellant evaporate rapidly, during which, the adhesive can freeze for a few seconds. In high humidity, moisture can settle on the adhesive, so when you try to bond your surfaces, there is a barrier of water and they won't stick. This is called the Blooming Effect.

To prevent this effect, you can spray the adhesive in an air conditioned area, in front of a fan, or just wait a little longer for the adhesive to tack, so the water can evaporate and your surfaces will stick as usual.

Please check your adhesive is tack ready with the back of your hand before bonding your substrates.